

# **TRIAx A/S**

# **TDX/TDH800 Release**

# **4.9.1.41674**

---

## **SUMMARY**

**Release description of TDX and TDH800 software release**

---

## Table of Content

<b>Table of Content</b> .....	<b>2</b>
<b>1 Introduction</b> .....	<b>3</b>
<b>2 Requirements</b> .....	<b>3</b>
<b>3 New features</b> .....	<b>3</b>
<b>4 Bug fixes</b> .....	<b>3</b>
<b>4.1 BE-PAL, BE-QAM, BE-COFDM:</b> .....	<b>3</b>

## ***TDX & TDH800 Public Release Description***

### **1 Introduction**

**Purpose of this document is in short to describe features delivered in the software version it refers to.**

### **2 Requirements**

**This release supports all TDX and TDH800 hardware, except prerelease modules shipped without serial number (before 2010-12-08).**

### **3 New features**

**List of new features added in release 4.9.1.41674, since last release 4.9.1. 41317.**

**None new features.**

### **4 Bug fixes**

**List of bug fixes corrected in release 5.0.1.41674, since last release 4.9.1.41674.**

#### **4.1 BE-PAL, BE-QAM, BE-COFDM:**

**Issue not possible to output at S19-S32 is now solved. The output frequency was mis adjusted to a random frequency.**