

Software versions

Improvements / Changes of firmware 2.3

MCT 048/048B/049/049B/059/059B – March 2021 (v2.3)

- Improvement of channel measurement plan for German cable TV
- Minor bug correction

Improvements / Changes of firmware 2.2

MCT 048/048B/049/049B/059/059B – September 2020 (v2.2)

- Power supply for Optical LNB added with RF input (only 7859B)
- Minor bug correction

Improvements / Changes of firmware 1.5

MCT 048 / 049 / 059 - February 2018

- Improvement of remote supply current measurement
- Improvement of factory default parameters
- Minor bug correction

Improvements / Changes of firmware 1.3

MCT 048 / 049 / 059 - June 2017 (v1.4) & December 2016 (v1.3)

- Improvement of the speed of satellite alignment (pointer)
- Improvement of remote supply current measurement
- MCT 059 with optical input
- Minor bug correction

Improvements / Changes of firmware 1.2

MCT 048 / 049 - April 2016

- Auto power-off added on home page
- Minor bug correction

Improvements / Changes of firmware 1.1

MCT 048 / 049 - November 2015

- Confirmation message added when importing a setup from USB
- Minor bug correction

Important reminder : before updating the internal firmware, please be sure to save your instrument setup.

MCT 048/048B/049/049B/059/059B – Software update process

We recommend that you make a backup of all instrument settings before doing the update.





Attention: Take care that the remaining battery life is sufficient (> 30%), else plug the instrument on the mains with the provided adapter.

MCT 048/048B:

You can easily update the software to get new functionalities. The update requires an USB stick.




To achieve the update:

- Download the update file "784X" on our website (www.triax.com)
- Insert a USB stick on your PC
- Unzip the file onto the root of the memory stick
- Pull the USB stick off from your computer
- Turn your instrument on
- Select a satellite or terrestrial menu, press configuration  Configuration
- Insert the USB stick into the connector of the instrument.
- Select Software update:  Software update

MCT 049/049B:

You can easily update the software to get new functionalities. The update requires an USB stick.



To achieve the update:

- Download the update file "784X" on our website (www.triax.com)
- Insert a USB stick on your PC
- Unzip the file onto the root of the memory stick
- Pull the USB stick off from your computer
- Turn your instrument on
- Go on the Home page , press configuration  Configuration
- Insert the USB stick into the connector of the instrument.
- Select Software update:  Software update

MCT 059/059B:

You can easily update the software to get new functionalities. The update requires an USB stick.

To achieve the update:

- Download the update file "784X" on our website (www.triax.com)
- Insert a USB stick on your PC
- Unzip the file onto the root of the memory stick
- Pull the USB stick off from your computer
- Turn your instrument on
- Select the optical or RF mode, press configuration  Configuration
- Insert the USB stick into the connector of the instrument.
- Select Software update:  Software update

Historique des versions logicielles

Rappel : avant la mise à jour de votre appareil, vous devez faire une sauvegarde de votre configuration

Améliorations / modifications de la version 2.3

MCT 048/048B/049/049B/059/059B – Mars 2021 (v2.3)

- Ajout du plan de fréquences 'German Cable'
- Corrections de bugs mineurs

Améliorations / modifications de la version 2.2

MCT 048/048B/049/049B/059/059B – Septembre 2020 (v2.2)

- Ajout de télé-alimentation pour LNB optique sur prise RF (seulement sur 7859B)
- Corrections de bugs mineurs

Améliorations / modifications de la version 1.4 / 1.5

MCT 048 / 049 / 059 - Juin 2017 (v1.4) et Février 2018 (V1.5)

- Amélioration de la mesure de courant de télé alimentation
- Corrections de bugs mineurs

Améliorations / modifications de la version 1.3 / 1.4

MCT 048 / 049 / 059 - Juin 2017 (v1.4) et Décembre 2016 (v1.3)

- Amélioration de la vitesse de pointage
- Amélioration de la mesure de courant de télé alimentation
- Prise en charge du MCT 059 (entrée optique)
- Corrections de bugs mineurs

Améliorations / modifications de la version 1.2

MCT 048 / 049 - Avril 2016

- Ajout de l'arrêt automatique sur la page d'accueil
- Corrections de bugs mineurs

Améliorations / modifications de la version 1.1

MCT 048 / 049 - Novembre 2015



- Ajout d'un message de confirmation en importation de configuration USB
- Corrections de bugs mineurs

**Procédure de mise à jour du logiciel MCT 048/048B/049/049B/059/059B**




Attention : assurer vous que l'autonomie de la batterie est suffisante (> 30%) sinon relier l'appareil au secteur avec l'adaptateur fourni.

Le logiciel peut être mis à jour facilement pour obtenir de nouvelles fonctionnalités. La mise à jour nécessite l'utilisation d'une clé mémoire USB. Il est fortement conseillé de faire une sauvegarde de tous les paramètres de l'appareil avant de faire la mise à jour.


Mise à jour d'un MCT 048/048B:

- Télécharger le fichier de mise à jour « 784X » sur notre site Internet (www.triax.fr),
- Insérer une clé mémoire USB sur votre PC.
- Dézipper le fichier à la racine de la clé.
- Retirer la clé USB de votre ordinateur.
- Mettre en marche votre appareil.
- Choisir le mode terrestre ou satellite, appuyer sur configuration 
- Insérer la clé mémoire USB dans le connecteur de l'appareil.
- Sélectionner Mise à jour 

Mise à jour d'un MCT 049/049B:

- Télécharger le fichier de mise à jour « 784X » sur notre site Internet (www.triax.fr),
- Insérer une clé mémoire USB sur votre PC.
- Dézipper le fichier à la racine de la clé.
- Retirer la clé USB de votre ordinateur.
- Mettre en marche votre appareil.
- Aller dans la page Home , appuyer sur configuration 
- Insérer la clé mémoire USB dans le connecteur de l'appareil.
- Sélectionner Mise à jour 

Mise à jour d'un MCT 059/059B:

- Télécharger le fichier de mise à jour « 784X » sur notre site Internet (www.triax.fr),
- Insérer une clé mémoire USB sur votre PC.
- Dézipper le fichier à la racine de la clé.
- Retirer la clé USB de votre ordinateur.
- Mettre en marche votre appareil.
- Choisir le mode optique ou le mode RF, appuyer sur configuration 
- Insérer la clé mémoire USB dans le connecteur de l'appareil.
- Sélectionner Mise à jour 